



Исполнения редукторов

AM/1 - AR/1 - AC/1

	AM... (IEC)	AM...	AR...	AC...
P				
F1 F2 F3				




Исполнения редукторов

AM/2-3 - AR/2-3 - AC/2-3

	AM... (IEC)	AM...	** AR...	* AC...
— 25 35			—	
P 25 - 120				
F1 F2 F3 25 - 120				
P/F 40 - 50 60 - 80 - 120				
P/F1 P/F2 P/F3 25 - 120				

Положение клемной коробки

1- СТАНДАРТ



Направление вращения

